



# PLATFORM SCALES


Line: Electronic Scale

Brand: TORREY

Model: PLP2500-4 , PLP5000-4 . PLP2500-5 , PLP5000-5

Page 1-15

FROM THE SERIAL NUMBER: G14-XXXXXX (ALL PLATFORMS)





## PLATFORM SCALES

Line: Electronic Scale

Brand: TORREY

Model: PLP2500-4 , PLP5000-4 . PLP2500-5 , PLP5000-5


Page 1-15

FOR MODELS PLP-4/4-2500/5000 y PLP-5/5-2500/5000

No.	Description.	Code
Ø1	2.5 KLB MOD. 3411 LOAD CELL (2500/5000 PLATFORMS)	B-20100029
Ø1	5KLB MOD. SUL LOAD CELL (5000/10000 PLATFORMS)	B-20100126
Ø2	#MS8 (3M) PINGOOD BOARD HOLDER	B-12400118
Ø3	SUM CARD ASSEMBLED	B-36600005
Ø4	WI L-PLP MODULE KIT	SEE SHEET 2
Ø5	*PLATFORM HARNESS L-PLP SERIES ASSEMBLED	B-46601168
Ø6	BASE SUPPORT FOR LOAD CELL PLP	B-22100141

\*PART NOT REPRESENTED

FROM THE SERIAL NUMBER: G14-XXXXXX (ALL PLATFORMS)





## PLATFORM SCALES

Line: Electronic Scale

Brand: TORREY

Model: PLP2500-4 , PLP5000-4 . PLP2500-5 , PLP5000-5

Page 1-14

FOR MODELS PLP-4/4-2500/5000 y PLP-5/5-2500/5000

No.	Description.	Code
Ø1	WI INDICATOR 3D KEYBOARD	B-20200519
Ø2	WI NT PROTEK INDICATOR MODULE OVERLAY	B-23300221
Ø3	WI MODULE KIT (CASE)	B-36700345
Ø4	TMWISTRØ MASTERBOARD ASSEMBLED	B-46601169
Ø5	6V 900 [mAh] NiMH BATTERY ASSEMBLED	B-46601077
Ø6	WI MH BATTERY HARNESS ASSEMBLED	B-46601073
Ø7	* WI MODULE HARNESS FOR PLP SERIES ASSEMBLED	B-46601170

\*PART NOT REPRESENTED